

## [Legacy] Driver for Easy VHS to DVD 3 Plus device

• Roxio Easy VHS to DVD Plus

## Warning:

This article references device drivers or patch updates that are obsolete. Installing these drivers or patches on current systems may cause system instability or corruption.

Issue: After installing Easy VHS to DVD 3/Plus, the device is not recognized by the software or receive a Windows prompt install driver for Roxio Video Capture USB

## Resolution:

Please click on the links below to download the driver for your system. You can tell if you have a 32- or 64-bit system but right click on My Computer then select Properties. It will be listed in System Type.

32-bit Windows

## 64-bit Windows

Please note the drivers above only apply to the device that's bundled with Easy VHS to DVD 3/Plus.

© 1985-2024 Corel. All rights reserved.