



Audio is not heard from the PC speakers during DV capture with Studio.

- Pinnacle Legacy

With Studio and a 1394 capture card, this is a normal condition. There is no audio preview during DV capture except from the DV or Digital 8 camcorder's speaker. We recommend that you increase the audio playback volume on the camcorder if available if you would like to hear the tapes audio during capture.