

## <u>Picture brightness is not as expected on TV after using Roxio</u> <u>Game Captue HD PRO device</u>

• Corel Other

Issue:

How do I adjust the picture brightness on TV if the pass through with Roxio Game HD PRO is not what I expected?

Resolution:

Roxio Game Capture HD PRO leverages USB cable to gain power from a connected laptop/PC. Thus no power adapter is required. However, the brightness of TV picture may get affected depending on different brands/models of TV or setup etc. You are recommended to have USB connected with a PC/laptop especially when you use Component cable to connect between the console and Roxio Game Capture HD PRO device. You can also use your TV remote controller to adjust the TV brightness as another option.

© 1985-2024 Corel. All rights reserved.