

The status shows ?No Signal? in the Capture application for Roxio Game Capture HD PRO

• Corel Other

Issue:

Why does the status show as ?No Signal? in the Capture application?

Resolution:

It means Roxio Game Capture HD PRO device can?t detect video signal from the console you connect to.

There are a couple of possibilities:

- 1. The console is not power on
- 2. Cable connection is not setup properly according to the Getting Started Guide
- 3. Video source is not supported. For example, if you are connection to a PS3, HDMI signal can?t be detected by Roxio Game Capture HD PRO device due to HDCP (protected video) by Sony. We suggest you to switch to Component (A/V) cable to connect between PS3 and Roxio Game Capture HD PRO. Please follow the instructions of PS3 setup on Getting Started Guide.
- 4. The capture device or cable could be damaged

© 1985-2024 Corel. All rights reserved.